

Sugar Refining

On-Line Measurement of Color and Clarity in Process Liquor for Production and Quality Control

There are several points in the process where measurements are made:

- Downstream of the filter presses, to determine the load on the color removal stage. Typical ranges are 0 to 1000 or 0 to 2500 color units.
- Downstream of the color removal stage for quality control or as a way of determining when to take the color removal column off-line for regeneration, instead of uneconomical time-based sequencing. In this latter application there is usually one analyzer per bed. Typical ranges are 0 to 100 or 200 color units.
- On the liquid sugar product line for quality assurance purposes. Typical ranges are 0 to 10 color units.
- Monitoring the color of the raw sugar melt to provide loading information for the downstream color removal process or for information on the load to the clarifier. Typical range 0 to 7000 color units.
- Lower grade sugar is often sold as table syrup and color is an important quality control parameter because the public expects a consistent color product, relating taste to color. Typical range 0 to 250 color units.

- Downstream of the decolorization stage to detect organic material. By monitoring in the UV region of the spectrum, organic materials can be detected which will ultimately result in color formation, but they can be detected with much higher sensitivity. This measurement can then be used to switch decolorizing columns rather than either waiting for color breakthrough or switching beds on a timed basis. This yields a lower cost, higher quality operation.

Product clarity measurement is important downstream of the filter presses to ensure proper filter operation and catch breakthrough before contaminating the char beds. It has been shown that although on a time-averaged basis, the filtered liquor may only show a particulate level of 10 -20 ppm, there are periods at start-up and break-through of individual presses when the levels are as high as 500 ppm.

Color Analyzer

The AMETEK Model 4000 color and turbidity analyzer is based on a rugged photometric analyzer which has been used for continuous on-line analysis in the petroleum refining, chemical processing, petro-chemical, pulp and paper, and food industries for more than 30 years.

This unit uses the split-beam technique for high reliability. Light passes through a sample cell which is physically separated from the lamp and detector. The transmitted light is split into two beams by a semi-transparent mirror. One beam passes through an optical filter to isolate a “measuring” wavelength. The other beam passes through an optical filter which isolates a wavelength where the color forming products do not absorb light or “reference” wavelength. The difference between these two beams, after logarithmic conversion, is directly and linearly proportional to absorbance at the measuring wavelength; and the analyzer is calibrated directly in ICUMSA color units. Particulate matter in the sample stream, such as filter breakthrough, affects both beams equally; and since the difference is used to determine the color, the color scale is not affected by particulates or bubbles. Analyzer stability and reliability are extremely high since there are no moving parts. Maintenance is usually confined to zero and calibration check during plant shut-downs. For ease of use, an optical calibration filter is built into the unit for use at any time by unskilled personnel.

Note that this technique gives direct color analysis without requiring the liquor to be filtered.

continued on page 2

(An exception to this statement is the application prior to the filter presses where coarse filtration is required to remove “rocks” which would otherwise plug the sample lines. A suitable self-cleaning filter eliminates maintenance).

When product clarity measurement is required combined with color measurement, then a second output is provided. This signal is based on the amount of light absorbance taking place at the reference wavelength which is solely due to particulates and independent of color. This provides a highly cost-effective solution for two measurements, since not only the cost of a second analyzer is avoided, but also the installation costs.

For organic, color-forming measurements, the same type of analyzer is used, but the measuring wavelength is changed to 365nm where the color formers are strong UV absorbers. All other aspects of analyzer operation are the same. of light absorbance taking place at the reference wavelength which is solely due to particulate and independent of color. This provides a highly cost-effective solution for two measurements, since not only the cost of a second analyzer is avoided, but also the installation costs.

For organic, color-forming measurements, the same type of analyzer is used but the measuring wavelength is changed to 365nm where the color formers are strong UV absorbers. All other aspects of analyzer operation are the same.

Measurement of “brilliance” is defined as the transmittance wavelength of 546nm. (Both measuring and reference wavelengths are emission lines from a mercury vapor lamp which are highly intense, extremely stable and highly accurate. This results in higher accuracy, higher linearity, and lower drift than a broad-band source/interference filter combination.) By taking a signal directly from the reference detector, a measurement of “brilliance” is provided from the same analyzer that measures product color. This is a significant reduction in purchase and installation costs. Further, the output is continuous and does not need to wait for laboratory analysis.



455 Corporate Blvd., Newark DE 19702
Ph. 302-456-4400, Fax 302-456-4444
www.ametekpi.com



© 2006, by AMETEK, Inc.
All rights reserved. Printed in the U.S.A.
Sugar Refining (06/07/07)

SALES AND MANUFACTURING:

Canada - Alberta
2876 Sunridge Way N.E., Calgary AB T1Y 7H9 • Tel: 403-235-8400, Fax: 403-248-3550

USA - Oklahoma
2001 N. Indianwood Ave., Broken Arrow OK 74012 • Tel: 918-250-7200, Fax: 918-459-0165

USA - Pennsylvania
150 Freeport Road, Pittsburgh PA 15238 • Tel: 412-828-9040, Fax: 412-826-0399

WORLDWIDE SALES AND SERVICE LOCATIONS:

USA - Texas
Tel: 281 463 2820, Fax: 281 463 2701

CHINA
Beijing / Tel: 86 10 8526 2111, Fax: 86 10 8526 2141
Chengdu / Tel: 86 28 8675 8111, Fax: 86 28 8675 8141
Shanghai / Tel: 86 21 6426 8111, Fax: 86 21 6426 7818

FRANCE
Tel: 33 1 30 68 89 20, Fax: 33 1 30 68 89 29

GERMANY
Tel: 49 21 59 91 36 0, Fax: 49 21 59 91 3639

MIDDLE EAST - Dubai
Tel: 971 4 881 2052, Fax: 971 4 881 2053

SINGAPORE
Tel: 65 6484 2388, Fax: 65 6481 6588